

ErgoPerfect[®]

How to Build the Power and Comfort Chairs



1

Attach the back brace and stem to the seat back with the bolts provided and a 5mm Allen wrench. Set aside.



2

Insert caster stems into round sleeves on the underside of the star base feet.



3

Insert bottom of the cylinder into the hole at the center of the star base.



4

Align hole at the bottom of the seat mechanism with the stem on the cylinder and insert.



5

Align the bottom of the seat back stem into the oblong hole at the back of the seat mechanism and slide it to the desired depth. Lock the back in place with the hand wheel bolt.



6

Once the chair is assembled, adjust the seat height, the depth and height of the back, and the angle of the seat with the hand wheel and paddles mounted to the seat mechanism.